

PRECISE

*racin*g chair

Precise Component Assembly

NO TOOLS REQUIRED

1 Turn your AK 200 Precise edition gaming chair upside down and slide the rear stabilizers onto the rear legs, placing smooth sides in and contoured sides facing out. Turn the chair right side up and add the front stabilizers by lining up the post of the front stabilizer with the hole in the bottom of the chair rocker.



2 Take the controller stand and lifting the front of the AK 200 Precise edition, place the round tube under the cutouts in the front leg supports. Line up the rectangular upright tube with the center of the chair seat and lower the AK 200 precise edition back onto the floor. The cutouts in the front leg supports should have captured the round tube. Allow the square tube to rotate so that is laying on the floor.

3 Place your pedals in position in front your chair and have your wheel ready. Sit down in the AK 200 Precise edition, rotate the game stand from the floor until it is up against the front of the seat base. Extend the open latch to connect with the metal loop on the stand and close by pushing firmly to the seat. Place your wheel on the wheel support and clamp it down. Adjust the angle of your wheel by loosening the wheel support clamp and then tightening the clamp once you are satisfied. Optimal wheel angle should be about 15 degrees, with your forearms parallel to the floor.

